

Data Sheet PD-1:PD-L1 Homogeneous Assay Kit Catalog # w82025

DESCRIPTION: The *PD-1:PD-L1 Homogeneous Assay Kit* is designed to measure the inhibition of PD-1 binding to PD-L1. The *PD-1:PD-L1 Homogeneous Assay Kit* comes in a convenient AlphaLISA[®] format with purified biotinylated PD-L1, FLAG-tagged PD-1, and assay buffer to perform a total of 384 reactions. With this kit, only three simple steps on a microtiter plate are required. First, a sample containing PD-1 and an inhibitor of choice is incubated with the biotinylated PD-L1 for 60 minutes. Next, acceptor beads are added, then donor beads, followed by reading the Alpha-counts.

COMPONENTS:

Catalog #	Component	Amount	Storage		
w81126	PD-1-FLAG	30 µg	-80 <i>°</i> C	· · · · · ·	
w81116	PD-L1-biotin	5 µg	-80°C	(Avoid freeze/	
	3x PD-1 assay buffer	4 ml	-20 <i>°</i> C	thaw cycles!)	

MATERIALS OR INSTRUMENTS REQUIRED BUT NOT SUPPLIED:

AlphaLISA FLAG acceptor beads, 5 mg/ml (PerkinElmer #AL112C) AlphaScreen Streptavidin-conjugated donor beads, 5 mg/ml (PerkinElmer #6760002S) Optiplate -384 (PerkinElmer #6007290) AlphaScreen microplate reader Adjustable micropipettor and sterile tips

APPLICATIONS: Useful for screening for inhibitors of PD-1 binding to PD-L1

CONTRAINDICATIONS: Only limited amounts of DMSO can be included, as it has been shown to disrupt PD-1-PD-L1 interaction. Avoid green and blue dyes that absorb light in the AlphaScreen signal emission range (520-620 nm), such as Trypan Blue. Avoid the use of the potent singlet oxygen quenchers such as sodium azide (NaN₃) or metal ions (Fe²⁺, Fe³⁺, Cu²⁺, Zn²⁺ and Ni²⁺). The presence of >1% RPMI 1640 culture medium leads to a signal reduction due to the presence of excess biotin and iron in this medium. MEM, which lacks these components, does not affect AlphaScreen assays.

STABILITY: At least one year from date of receipt when stored as directed.

REFERENCES: 1. Lin, D., *et al. Proc Natl Acad Sci U.S.A.* 2008, **105:** 3011-3016. 2. Keir, M.E. *et al. Annu. Rev. Immunol.* 2008, 26: 677-704.



ASSAY PROTOCOL:

All samples and controls should be tested in duplicate. Use slow shaking for all incubations.

Step 1:

- Thaw PD-1-FLAG on ice. Upon first thaw, briefly spin tube containing protein to recover full contents of the tube. Aliquot the protein into single use aliquots. Store remaining undiluted protein in aliquots at -80 °C immediately. Note: PD-1-FLAG is very sensitive to freeze/thaw cycles. Do not re-use thawed aliquots or diluted protein.
- Dilute one part 3x PD-1 assay buffer with 2 parts of distilled water (3-fold dilution) to make 1x PD-1 assay buffer. Make only a sufficient quantity needed for the assay; store remaining stock solution in aliquots at -20 °C.
- 3) Dilute **PD-1-FLAG** in **1x PD-1 assay buffer** to 25 ng/μl. Keep diluted protein on ice until ready to use. Discard any remaining unused diluted protein after use.
- 4) Prepare the master mixture: N wells × (2 μl **3x PD-1 assay buffer** + 2 μl diluted **PD-1**-**FLAG +** 2 μl distilled water). Add 6 μl of master mixture to every well.

	Blank	Positive Control	Test Inhibitor
3x PD-1 assay buffer	2 µl	2 µl	2 µl
PD-1-FLAG (25 ng/µl)	2 µl	2 µl	2 µl
Distilled water	2 µl	2 µl	2 µl
Test Inhibitor	_	_	2 µl
Inhibitor buffer (no inhibitor)	2 µl	2 µl	_
1x PD-1 assay buffer	2 µl		
PD-L1-biotin (3 ng/µl)	_	2 µl	2 µl
Total	10 µl	10 µl	10 µl

- 5) Add 2 μl of inhibitor solution to each well designated "Test Inhibitor". For the "Positive Control" and "Blank", add 2 μl of the same solution without inhibitor (inhibitor buffer). *Note: If possible, keep final DMSO concentration below 0.5 %.*
- 6) Add 2 μl of 1x PD-1 assay buffer to the well designated "Blank".
- 7) Thaw PD-L1-biotin on ice. Upon first thaw, briefly spin tube containing protein to recover full contents of the tube. Aliquot the protein into single use aliquots. Store remaining undiluted protein in aliquots at -80°C immediately. Note: PD-L1-biotin is very sensitive to freeze/thaw cycles. Do not re-use thawed aliquots or diluted protein.



- 8) Dilute **PD-L1-biotin** in **1x PD-1 assay buffer** to 3 ng/μl. Keep diluted proteins on ice until use. Discard any remaining unused diluted protein after use.
- Initiate reaction by adding 2 μl of diluted PD-L1-biotin prepared as described above to each well designated "Positive Control" and "Test Inhibitor". Incubate at room temperature for 60 minutes.

Step 2:

Note: Protect your samples from direct exposure to light!

1) Dilute FLAG Acceptor beads (PerkinElmer #AL109C) 250-fold with **1x PD-1 assay buffer**. Add 10 μl per well. Shake plate briefly. Incubate at room temperature for 30 minutes.


Step 3: Note: Protect your samples from direct exposure to light!

- 1) Dilute Streptavidin-conjugated donor beads (PE #6760002S) 125-fold with **1x PD-1 assay buffer**. Add 10 μl per well. Incubate at room temperature for 30 minutes.
- 2) Read Alpha-counts.

Due to lot to lot variability in AlphaScreen[®] bead performance, it may be necessary to optimize assay conditions. For example, slight adjustments to PD-1 or PD-1L concentrations may improve signal-to-noise ratio.



Example of Assay Results:



PD-1:PD-L1 inhibition, measured using the PD-1:PD-L1 Inhibitor Screening Assay Kit, West Bioscience, Catalog #w82025 and PD-L1 neutralizing antibody, Catalog#w81224. *Data shown is lot-specific.* For lot-specific information, please contact West Bioscience, Inc. at sale@westbioscience.com.